


**Pressure Detectors
(Meter Bodies)
for PREX3000 Series and
KF-B Series
User's Manual**



Azbil Corporation

NOTICE

While this information is presented in good faith and believed to be accurate,

Azbil Corporation disclaims the implied warranties of merchantability and fitness for a particular purpose and makes no express warranties except as may be stated in its written agreement with and for its customer.

In no event is Azbil Corporation liable to anyone for any indirect, special or consequential damages, The information and specifications in this document are subject to change without notice.

TABLE OF CONTENTS

	<u>PAGE</u>
DESCRIPTION	1
1. GENERAL	1
2. MODELS	1
3. INSTRUCTIONS FOR INSTRUMENTS (TRANSMITTERS AND CONTROLLERS) USED IN CONJUNCTION	1
STRUCTURES OF METER BODIES	2
1. EXTERNAL VIEWS	2
2. STRUCTURES AND OPERATING PRINCIPLES	3
INSTALLATION	5
1. GENERAL	5
2. BRACKET AND BOLTS	5
3. PLACE OF INSTALLATION	5
4. INSTALLATION METHOD	6
5. PRESSURE PIPING	8
6. ELEVATION AND SUPPRESSION	9
OPERATION METHOD	11
INSPECTION AND MAINTENANCE	12
APPENDIX A. SPECIFICATIONS, MODEL NO., EXTERNAL DIMENSIONS ... APPENDIX A	

DESCRIPTION

1. GENERAL

The pressure detector (meter body) accepts a process pressure with its pressure receiver element and converts the process pressure into a torque with its torque tube. The torque is applied to a pneumatic transmitter (Model KKP or KFKB) or a pneumatic controller (Model KFKB).

Some models of detectors have a flange incorporated with a diaphragm for connection to the process.

2. MODELS

Measured Pressures or Type of Instrument	Model Numbers of Instruments Used in Conjunction	Operator's Manual Used in Conjunction
High Gauge Pressures	Models KKP11/12/13/14 Models KFKB11/12/13/14	OM2-5220-0000 (KKP) OM2-6220-0000 (KFKB)
Low Gauge Pressures	Models KKP15/16/17/18 Models KFKB15/16/17/18	
Absolute Pressures	Models KKP25/26/27/28 Models KFKB25/26/27/28	
Remote Sealed Diaphragm Type	Models KKP71/72/73/74/ 75/76 Models KFKB71/72/73/74/ 75/76	

3. INSTRUCTIONS FOR INSTRUMENTS (TRANSMITTERS AND CONTROLLERS) USED IN CONJUNCTION


For the instructions for instruments used in conjunction, refer to respective Operator's Manuals which cover the operating principles, service and unit replacement procedures, and calibration and adjustment procedures of these instruments.

STRUCTURES OF METER BODIES


1. EXTERNAL VIEWS

Although external views of meter bodies differ by models as shown in Figure 1, the bracket mounting section and instrument connection section are identical for all models.





MODELS 11/12/13/14



MODELS 15/16





MODELS 17/18
MODELS 25/26/27/28



(Meter bodies as coupled to respective instruments)

MODELS 71/72/73/74/75/76




(Meter body as coupled to instrument)


Figure 1

2. STRUCTURES AND OPERATING PRINCIPLES

The operating principles of the pressure detectors (meter bodies) are illustrated in Figures 2 through 7.




- ① FLANGE
- ② PRESSURE RECEIVER ELEMENT (BOURDON)
- ③ TORQUE ARM
- ④ TORQUE TUBE
- ⑤ BODY
- ⑥ COVER




- ① FLANGE
- ② PRESSURE RECEIVER ELEMENT (BELLOWS)
- ③ TORQUE ARM
- ④ TORQUE TUBE
- ⑤ BODY
- ⑥ COVER

Figure 2. Operating Principle of Model 11/12/13/14 Meter Body (Bourdon Element)

Figure 3. Operating Principle of Model 15/16 Meter Body (Bellows Element)




- ① COVER
- ② PRESSURE RECEIVER ELEMENT (BELLOWS)
- ③ TORQUE ARM
- ④ TORQUE TUBE
- ⑤ BODY
- ⑥ COVER




- ① COVER
- ② PRESSURE RECEIVER ELEMENT (BELLOWS).
- ③ TORQUE ARM
- ④ TORQUE TUBE
- ⑤ BODY
- ⑥ STOPPER
- ⑦ VACUUM CHAMBER

Figure 4. Operating Principle of Model 17/18 Meter Body (Bellows Element)

Figure 5. Operating Principle of Model 25/26/27/28 Meter Body



- ① PROCESS PRESSURE TAPPING FLANGE
- ② SEAL DIAPHRAGM
- ③ PRESSURE RECEIVER ELEMENT (BOURDON TUBE)
- ④ TORQUE ARM
- ⑤ TORQUE TUBE
- ⑥ BODY
- ⑦ COVER



- ① PROCESS PRESSURE TAPPING FLANGE
- ② SEAL DIAPHRAGM
- ③ PRESSURE RECEIVER ELEMENT (BELLOWS)
- ④ TORQUE ARM
- ⑤ TORQUE TUBE
- ⑥ BODY
- ⑦ COVER

Figure 6. Operating Principle of Model 71/72/73/74 Meter Body (Bourdon Element)

Figure 7. Operating Principle of Model 75/76 Meter Body (Bellows Element)

The process pressure is fed through the flange or cover (and via the seal liquid in the case of a remote-sealed type) to the pressure receiver element which exercises a rotational force on the torque arm. The torque arm drives the torque tube through which a torque force representing the process pressure is applied to the beam of the instrument.

The reference-pressure chamber of the absolute-pressure detector (meter body) is kept vacuum.

INSTALLATION


1. GENERAL

The meter body (detector), together with the instrument (transmitter) coupled to it, can be installed on a 50-mm pipe stanchion by using the accessory bracket and U-shape bolt.

Model 61/62 meter body can be installed simply by fixing its flange to the process.

2. BRACKET AND BOLTS

The bracket and bolts for installation are supplied accompanying the meter body.



3. PLACE OF INSTALLATION

When selecting a place of installation for the instrument, take into consideration the matters related to instrument inspection, maintenance, longevity, and operation safety as follows:

- (1) Select a place where temperature change is small (within the limits of -30°C to $+80^{\circ}\text{C}$). Avoid a place where the instrument is exposed to high temperature by radiation from a source of heat.

When water is measured, pay attention to freezing which may cause damage to the meter body. Provide appropriate means to guard against freezing.

- (2) Select a place where is reasonably free from humidity and vibration.
- (3) Be sure to provide spaces for inserting a screwdriver for adjustment and span change.

4. INSTALLATION METHOD

4.1 Installation of Regular-type Meter Body

The meter body, together with the transmitter coupled to it, can be installed in either one of the following methods:

- o Pipe stanchion mount
- o Process pipe mount

In either case, fix the meter body to a 50-mm vertical or horizontal pipe using the mounting bracket and U-shape bolt. Fix the pipe securely to a foundation so that the pipe does not sway. (See Figure 10.)

To install the meter body on a process pipe line, prepare brackets for mounting the 50-mm pipe to the process pipe. (See Figure 9.)

When installing a remote-sealed type of meter body, exercise care not to sharply bend or twist the capillary tube and not to damage the diaphragm.




Figure 9. Example of line mount bracket

Note: When installing the transmitter (meter body) on a 50-mm pipe, note that the order of mountings (transmitter, bracket, and 50-mm pipe) differs depending on the mounting direction.




Figure 10. Installation examples

4.2 Installation of Remote-Sealed Diaphragm Type Meter Body

This type of meter body can be fixed to a pipe stanchion in the same manner as in the case of the regular type of meter body. For connection to the process, proceed as follows:

- (1) Connect the tapping flange to the process flange with the bolts and gasket. Evenly tighten the bolts to prevent leak. Lay the capillary tube so that it is less subjected to temperature change and fix it so that it does not move.

It is recommendable to install the transmitter at a location lower than the flange.

- (2) If the zero point shift has been caused by the head pressure of the seal liquid due to the difference in height between the center of the flange and the center of the pressure receiver, adjust zero by means of the ZERO control (or ELEVATION or SUPPRESSION control). The specific-gravity of the seal liquid is 0.935 at 20°C (For temperature compensation, use a factor of 0.001/°C).
- (3) For installation of the button diaphragm, refer to its dimension drawing.

When the installed button diaphragm is required to be pulled out, set the collar available as an option to the groove at the rear end of the element (capillary tube side) and retract the screw.

5. PRESSURE PIPING

5.1 The pressure piping method (tapping pressure connection method) for the meter body (transmitted) differs by installation position of the meter body, by the type of the process pipe, and other conditions of measurement.

5.2 Typical examples of pressure piping methods are shown in Figure 11. For piping, observe the following instructions.

- (1) Install a tee joint in the pressure tap line.
- (2) Install a stop valve between the pressure tap point and the tee joint.
- (3) For the pressure connection piping from the tap point of a horizontal process pipe to the meter body, provide a gradient so that drain is returned through the tap point to the process pipe.

Note: To measure a high pressure, pay attention to the types of joints, and pipe dimensions and materials.

- (4) For pressure piping from the process pipe to the transmitter, use an appropriate type (appropriate schedule number and nominal thickness) of pipes depending on the process pressure and other measuring conditions. An example is a 1/2 inch Schedule 80 steel pipe. Copper pipes are used in general for measurement of water or steam pressures.

5.3 Auxiliary Devices

- (1) Oil Seal and Air Purge

When it is undesirable to lead directly the measured pressure medium (fluid with suspension, highly viscous fluid, or corrosive fluid) to the pressure transmitter, use liquid seal or air purge. Various liquid seal and air purge methods are possible. For details, please consult an Azbil Corp. representative.

- (2) Pulsation Damping

When the process pressure pulsates or otherwise varies abnormally rapidly, install a restriction valve in the pressure piping in order to smooth out such rapid pressure change.




Figure 11. Examples of pressure tap piping

6. ELEVATION AND SUPPRESSION

6.1 Definitions of Elevation and Suppression

The terms "elevation" and "suppression" as used in this publication are defined as follows:

Elevation: Synonymous with "suppressed zero range"

An input range whose low end value is higher than zero. For example, a range of 20 to 100.

Suppression: Synonymous with "elevated zero range"


An input range whose low end value is lower than zero. For example, a range of -20 to 0.

6.2 Setting of Elevation/Suppression

For setting of elevation/suppression, refer to Section "CALIBRATION AND ADJUSTMENT" of Operator's Manual for Pneumatic Transmitter OM2-5220-0000.

When calculating the head pressure of the seal liquid of Model 71/72/73/74/75/76, multiply the level difference between the center of diaphragm and the center of detector by the specific-gravity of seal liquid (0.935*) and take the product value for the elevation.

* See 4.2 (2)



Note: Elevation alone is applicable to Model 25/26/27/28. To other models, suppression is applicable for vacuum pressures.

Figure 12

OPERATION METHOD

The meter body, together with the transmitter coupled to it, starts operating as the air supply and process input are fed to it. (It is recommendable to check the operation of the transmitter before starting the running operation.)

- (1) Measurement of Liquid or Gas Pressure (Except Vacuum Pressure Process)

Close the block valve, open the bleed valve, and then open the stop valve in order to blow the pressure piping to eliminate foreign matter from inside the piping. Next, close the bleed valve, wait until the pressure piping is cooled off if process temperature is high, and then open the block valve to lead process liquid or gas to the meter body. (No bleed is required for vacuum pressure processes.)

- (2) Measurement of Steam Pressure

The operating procedure is the same as that for liquid or gas pressure measurement of (1), except the following: After blowing the pressure piping to eliminate foreign matter and closing the bleed valve, condense steam so that the pressure piping and siphon are filled with water, and then open the block valve.

- (3) Correction for Installation Height of Transmitter

When a liquid pressure is measured or when there is condensed steam in the pressure piping, correction should be made, as required, for the head pressure which depends on the height of installation of the transmitter. (This will be required especially when measuring low pressures.) For this correction, shift the zero point of the transmitter by an amount corresponding to the differential height between pressure tapping point and transmitter installation position multiplied by the specific gravity of the liquid. (Elevation)

- (4) Zero Point Check

When the instrument has become the measuring state, check and adjust the zero point with the receiver connected to the transmitter.

INSPECTION AND MAINTENANCE

For routine inspection and maintenance, pay attention to the following:

1. CHECK FOR LEAK FROM PIPING

Check that there is no leak in the piping from the pressure tap points to the meter body. If any loose connections are found, tighten them securely.

2. BLOW AND CLEANING OF METER BODY AND PIPING

To maintain constantly the instrument at its best performances meeting its specification accuracy, keep clean the meter body and its piping. If sediment or other foreign matters are entrapped in the pressure chambers of the meter body, measuring errors may be caused. To blow and clean the meter body and piping, proceed as mentioned in the following referring to Section 5 "PRESSURE PIPING" of Part "INSTALLATION."

1. Close the stop valve.
2. With the block valve kept open, rapidly open the bleed valve.
3. Close the bleed valve and open the stop valve.

For a vacuum pressure process, blow the piping only when the process is at a positive pressure.

No blowing is necessary for the remote-sealed diaphragm type of meter bodies.

3. NOTES FOR USE IN FREEZING SEASON

When the transmitter used for measurement of water or other freezable liquid is paused in a freezing season or area, loosen the bleed valve and drain out liquid from the pressure chambers to prevent freezing.

KF Series

Pressure Indicating Controller

Model KFK (Adjustable Range Type)

Introduction

The KF Series instruments are field installed type of pneumatic indicating controllers which are used to measure and control the various types of process variables such as temperatures, pressures, flows and liquid levels.

Model KFK Pressure Indicating Controllers (adjustable range type) indicate and control a process variable by converting its pressure into mechanical displacement of a bellows or a spiral pressure receiving element.

Indicating transmitters and indicating transmitting controllers also are available as well as indicating controllers. The controllers are available either in the local type to set the set-point value with the knob on the instrument or in the cascade type (remote type) to set the set-point value with a pneumatic signal.

Features

- A wide variety of measuring elements and control mechanisms are available to meet various applications.
- A pneumatic circuit board and a heat-resistant weatherproof sturdy case are used, thereby greatly improving the durability and reliability.
- The pneumatic circuit board system allows to readily add or eliminate control mechanisms and units, thereby enhancing the system modifications and expansion flexibility.
- Interchangeable parts are used to the maximum practicable extent, thereby reducing the number of parts to be kept in stock.
- The detecting section is identical with that of the pressure transmitter of PREX3000 Pneumatic Transmitter Series.



Standard Specifications

Item			Specifications					
Model No.	Pressure element	Measuring range	Process connection	Pressure limit	Allowable overload	Suppression (max.)	Elevation (max.)	
Detector	Bourdon tube	0-5 to 0-70 MPa {0-50 to 0-700 kgf/cm ² }	Welding nipple connection (φ13.6x50)	-0.1 to +70 MPa {-1 to +700 kgf/cm ² }	-0.1, 75 MPa {-1, 750 kgf/cm ² }	-100 kPa {-1 kgf/cm ² }	65 MPa {650 kgf/cm ² }	
		0-1.25 to 0-25 MPa {0-12.5 to 0-250 kgf/cm ² }		-0.1 to +30 MPa {-1 to +300 kgf/cm ² }	-0.1, 32 MPa {-1, 320 kgf/cm ² }		28.75 MPa {287.5 kgf/cm ² }	
		0-0.35 to 0-7 MPa {0-3.5 to 0-70 kgf/cm ² }		-0.1 to +10.5 MPa {-1 to +105 kgf/cm ² }	-0.1, 14 MPa {-1, 140 kgf/cm ² }		10.15 MPa {101.5 kgf/cm ² }	
		0-0.175 to 0-3.5 MPa {0-1.75 to 0-35 kgf/cm ² }		-0.1 to +5.25 MPa {-1 to +52.5 kgf/cm ² }	-0.1, 7 MPa {-1, 70 kgf/cm ² }		5.075 MPa {50.75 kgf/cm ² }	
	Bellows	0-35 to 0-686 kPa {0-0.35 to 0-7 kgf/cm ² }	Rc½ or Rc¼ internal thread ½NPT or ¼NPT internal thread	-0.1 to +1.05 MPa {-1 to +10.5 kgf/cm ² }	-0.1, 1.4 MPa {-1, 14 kgf/cm ² }	-66.6 kPa {-500mmHg}	1.015 MPa {10.15 kgf/cm ² }	
		0-10 to 0-196 kPa {0-0.1 to 0-2 kgf/cm ² }		-100 to +300 kPa {-1 to +3 kgf/cm ² }	-100, 400 kPa {-1, 4 kgf/cm ² }		290 kPa {2.9 kgf/cm ² }	
		0-3.4 to 0-66.6 kPa {0-0.25 to 0-500mmHg}		-66.6 to +66.6 kPa {-500 to +500 mmHg}	-66.6, 400 kPa {-500mmHg, 4 kgf/cm ² }		63.2 kPa {475 mmHg}	
		0-0.7 to 0-13.3 kPa {0-0.5 to 0-100mmHg}		-13.3 to +13.3 kPa {-100 to 100mmHg}	-13.3, 400 kPa {-100mmHg, 4 kgf/cm ² }		12.6 kPa {95mmHg}	
	Bellows (absolute pressure)	0-35 to 0-686 kPa abs. {0-0.35 to 0-7 kgf/cm ² abs.}	0 to 686 kPa abs. {0 to 7 kgf/cm ² abs.}	0 to 196 kPa abs. {0 to 2 kgf/cm ² abs.}	0.6 MPa abs. {6 kgf/cm ² abs.}	-	186 kPa abs. {1.9 kgf/cm ² abs.}	
		0-10 to 0-196 kPa abs. {0-0.1 to 0-2 kgf/cm ² abs.}		0 to 66.6 kPa abs. {0 to 500mmHg} abs.	0.4 MPa abs. {4 kgf/cm ² abs.}		63.2 kPa abs. {475mmHg} abs.	
		0-3.4 to 0-66.6 kPa abs. {0-0.25 to 0-500mmHg} abs.		0 to 13.3 kPa abs. {0 to 100mmHg} abs.	0.4 MPa abs. {4 kgf/cm ² abs.}		12.6 kPa abs. {95mmHg} abs.	
		0-0.7 to 0-13.3 kPa abs. {0-0.5 to 0-100mmHg} abs.						
	Remote seal diaphragm	0-5 to 0-70 MPa {0-50 to 0-700 kgf/cm ² }	G1½ external thread (φ34 button diaphragm)	-0.05 to +70 MPa {-1 to +700 kgf/cm ² }	-0.05, 70 MPa {-1, 750 kgf/cm ² }	-0.05 MPa {-0.5 kgf/cm ² }	65 MPa {650 kgf/cm ² }	
				0-1.25 to 0-25 MPa {0-12.5 to 0-250 kgf/cm ² }	G1¼ external thread (φ34 button diaphragm) or 2"-ANSI wafer		-0.05 to +30 MPa {-1 to 300 kgf/cm ² }	-0.05, 32 MPa {-1, 320 kgf/cm ² }
		0-0.35 to 0-7 MPa {0-3.5 to 0-70 kgf/cm ² }	2"-ANSI wafer				-0.05 to +10.5 MPa {-1 to 105 kgf/cm ² }	-0.05, 14 MPa {-1, 140 kgf/cm ² }
				0-0.175 to 0-3.5 MPa {0-1.75 to 0-35 kgf/cm ² }	80mm-JIS30K flush diaphragm 100mm-JIS30K extended diaphragm		-0.05 to +5.25 MPa {-1 to +52.2 kgf/cm ² }	-0.05, 7 MPa {-1, 70 kgf/cm ² }
		3"-ANSI300 flush diaphragm 4"-ANSI300 extended diaphragm	-0.05 to +10.5 MPa {-1 to +105 kgf/cm ² }				-0.05, 5.1 MPa {-1, 51 kgf/cm ² }	4.925 MPa {49.25 kgf/cm ² }
			3"-ANSI150 flush diaphragm 4"-ANSI150 extended diaphragm				-0.05 to +3.82 MPa {-1 to +37 kgf/cm ² }	-0.05, 3.82 MPa {-1, 37 kgf/cm ² }
		0-35 to 0-686 kPa {0-0.35 to 0-7 kgf/cm ² }					80mm-JIS10K flush diaphragm 100mm-JIS10K extended diaphragm	-0.05 to +1.05 MPa {-0.5 to 10.5 kgf/cm ² }
			0-10 to 0-196 kPa {0-0.1 to 0-2 kgf/cm ² }	80mm-JIS10K flush diaphragm 100mm-JIS10K extended diaphragm	-0.05 to +0.3 MPa {-0.5 to +3 kgf/cm ² }			-0.05, 0.4 MPa {-0.5, 4 kgf/cm ² }

Note 1) Elevation + Span ≤ Max. span.

2) Refer to the annexed table about Max. working pressure on Remote seal diaphragm.

Max Working Pressure

Note1. Max Working Pressure depends on flange rating , flange materials and operating temperature. Please refer to the following data.

Operating range of temperature depends on specification of transmitters

Note2. In case of remote sealed type (KKP75,KFKB□□-75), Max Working Pressure depends on the smaller value of either 1.05MPa or following data.

	J I S	J P I / A N S I
Carbon steel	<p>Graph showing Max Working Pressure (MPa) vs Temperature (°C) for Carbon steel under JIS standards. The y-axis ranges from 0.0 to 6.0 MPa, and the x-axis ranges from -50 to 300 °C. Three curves are shown for ratings 30K, 20K, and 10K. The 30K curve starts at ~4.5 MPa, the 20K at ~3.0 MPa, and the 10K at ~1.5 MPa. All curves show a slight decrease in pressure as temperature increases.</p>	<p>Graph showing Max Working Pressure (MPa) vs Temperature (°C) for Carbon steel under JPI/ANSI standards. The y-axis ranges from 0.0 to 6.0 MPa, and the x-axis ranges from -50 to 300 °C. Two curves are shown for ratings 300# and 150#. The 300# curve starts at ~5.0 MPa and the 150# at ~2.0 MPa. Both curves show a significant decrease in pressure as temperature increases, especially above 50 °C.</p>
SUS304	<p>Graph showing Max Working Pressure (MPa) vs Temperature (°C) for SUS304 under JIS standards. The y-axis ranges from 0.0 to 6.0 MPa, and the x-axis ranges from -50 to 300 °C. Three curves are shown for ratings 30K, 20K, and 10K. The 30K curve starts at ~5.0 MPa, the 20K at ~3.5 MPa, and the 10K at ~1.5 MPa. All curves show a decrease in pressure as temperature increases.</p>	<p>Graph showing Max Working Pressure (MPa) vs Temperature (°C) for SUS304 under JPI/ANSI standards. The y-axis ranges from 0.0 to 6.0 MPa, and the x-axis ranges from -50 to 300 °C. Two curves are shown for ratings 300# and 150#. The 300# curve starts at ~5.0 MPa and the 150# at ~2.0 MPa. Both curves show a decrease in pressure as temperature increases.</p>
SUS316	<p>Graph showing Max Working Pressure (MPa) vs Temperature (°C) for SUS316 under JIS standards. The y-axis ranges from 0.0 to 6.0 MPa, and the x-axis ranges from -50 to 300 °C. Three curves are shown for ratings 30K, 20K, and 10K. The 30K curve starts at ~5.0 MPa, the 20K at ~3.5 MPa, and the 10K at ~1.5 MPa. All curves show a decrease in pressure as temperature increases.</p>	<p>Graph showing Max Working Pressure (MPa) vs Temperature (°C) for SUS316 under JPI/ANSI standards. The y-axis ranges from 0.0 to 6.0 MPa, and the x-axis ranges from -50 to 300 °C. Two curves are shown for ratings 300# and 150#. The 300# curve starts at ~5.0 MPa and the 150# at ~2.0 MPa. Both curves show a decrease in pressure as temperature increases.</p>
SUS316L	<p>Graph showing Max Working Pressure (MPa) vs Temperature (°C) for SUS316L under JIS standards. The y-axis ranges from 0.0 to 6.0 MPa, and the x-axis ranges from -50 to 300 °C. Three curves are shown for ratings 30K, 20K, and 10K. The 30K curve starts at ~4.5 MPa, the 20K at ~3.0 MPa, and the 10K at ~1.5 MPa. All curves show a decrease in pressure as temperature increases.</p>	<p>Graph showing Max Working Pressure (MPa) vs Temperature (°C) for SUS316L under JPI/ANSI standards. The y-axis ranges from 0.0 to 6.0 MPa, and the x-axis ranges from -50 to 300 °C. Two curves are shown for ratings 300# and 150#. The 300# curve starts at ~4.5 MPa and the 150# at ~1.5 MPa. Both curves show a decrease in pressure as temperature increases.</p>

Item		Specifications	
Function	Model No.	Measuring range	
	KFKB□□11/71	0-5 to 0- less than 10 MPa {0-50 to 0- less than 100 kgf/cm ² }	0-10 to 0-70 MPa {0-100 to 0-700 kgf/cm ² }
	" 12/72	0-1.25 to 0- less than 2.5 MPa {0-12.5 to 0- less than 25 kgf/cm ² }	0-2.5 to 0-25 MPa {0-25 to 0-250 kgf/cm ² }
	" 13/73	0-0.35 to 0- less than 0.7 MPa {0-3.5 to 0- less than 7 kgf/cm ² }	0-0.7 to 0-7 MPa {0-7 to 0-70 kgf/cm ² }
	" 14/74	0-0.175 to 0- less than 0.35 MPa {0-1.75 to 0- less than 3.5 kgf/cm ² }	0-0.35 to 0-3.5 MPa {0-3.5 to 0-35 kgf/cm ² }
	" 15/75	0-35 to 0- less than 68.6 kPa {0-0.35 to 0- less than 0.7 kgf/cm ² }	0-68.6 to 0-686 kPa {0-0.7 to 0-7 kgf/cm ² }
	" 16/76	0-10 to 0- less than 19.6 kPa {0-0.1 to 0- less than 0.2 kgf/cm ² }	0-19.6 to 0-196 kPa {0-0.2 to 0-2 kgf/cm ² }
	" 17	0-3.4 to 0- less than 6.66 kPa {0-25 to 0- less than 50mmHg}	0-6.66 to 0-66.6 kPa {0-50 to 0-500mmHg}
	" 18	0-0.7 to 0- less than 1.33 kPa {0-5 to 0- less than 10mmHg}	0-1.33 to 0- less than 9.3 kPa (**) {0-10 to 0- less than 70mmHg}
	" 25	0-35 to 0- less than 68.6 kPa abs. {0-0.35 to 0- less than 0.7 kgf/cm ² abs.}	0-68.6 to 0-686 kPa abs. {0-0.7 to 0-7 kgf/cm ² abs.}
	" 26	0-10 to 0- less than 19.6 kPa abs. {0-0.1 to 0- less than 0.2 kgf/cm ² abs.}	0-19.6 to 0-196 kPa abs. {0-0.2 to 0-2 kgf/cm ² abs.}
	" 27	0-3.4 to 0- less than 6.66 kPa abs. {0-25 to 0- less than 50mmHg} abs.	0-6.66 to 0-66.6 kPa abs. {0-50 to 0-500mmHg} abs.
	" 28	0-0.7 to 0- less than 1.33 kPa abs. {0-5 to 0- less than 10mmHg} abs.	0-1.33 to 0- less than 9.3 kPa abs. (**) {0-10 to 0- less than 70mmHg} abs.
Transmission/Indication		±1.0%FS/±1.5%FS	±0.5%FS/±1.0%FS
Note: *1) 0-9.3 to 0 to 13.3 kPa {0-70 to 0-100mmHg} Transmitting accuracy ±0.75%FS Indicating accuracy ±1.25%FS *2) 0-9.3 to 0 to 13.3 kPa {0-70 to 0-100mmHg} abs.; Transmitting accuracy ±0.75%FS Indicating accuracy ±1.25%FS			
Indication	Repeatability	Within 0.3% FS	
	Dead band	Within 0.1% FS	
	Angle	44 degrees	
	Scale length	150mm	
Set-point Section	Pointer	Process variable ; Red Setpoint value; Green	
	Output indicator (φ40mm)	Scale range; 0-200 kPa {0-2 kgf/cm ² }, Indicator accuracy; ±3% FS	
	Local setting	Internal or external setting by setting knob.	
Controller	Remote setting	Pneumatic pressure setting of 20-100 kPa {0.2-1.0 kgf/cm ² }	
	Setting range	0-100% FS	
	Control action	P + Manual reset, PI, PID, PD + Manual reset, PI + Batch, On-Off, Differential gap, P + External reset, PD + External reset	
	Proportional band (P)	5-500% (direct or reverse action)	
	Integral (I)	0.05-30 min.	
	Derivative (D)	0.05-30 min.	
	Differential gap	1-100% FS, adjustable	
	Batch setting pressure	60-110 kPa {0.6-1.1 kgf/cm ² }, adjustable	
General Specification	External reset pressure	20-100 kPa {0.2-1.0 kgf/cm ² }	
	Manual reset	0-100% FS, adjustable (by pneumatic pressure setting.)	
	Output	20-100 kPa {0.2-1.0 kgf/cm ² }, 0 or Supply air pressure (when on-off or differential gap control action)	
	Minimum load	I.D. 4mm x 3m + 20cm ³	
	Supply air pressure	140 ± 14 kPa {1.4±0.14 kgf/cm ² }	
	Air consumption (50% output balanced)	Indicating transmitter ; 9 Nℓ/min. Only indicating ; 5 Nℓ/min. Indicating controller ; 9 Nℓ/min. Manual control ; +3 Nℓ/min. Indicating transmitting controller ; 9 Nℓ/min.	
	Saturated air supply capacity	Pneumatic transmission : 40Nℓ/min. Output ; 40Nℓ/min. Manual pneumatic pressure ; 30Nℓ/min.	
	Air connection	Rc ¼ or ½ NPT internal thread	
	Ambient temperature	At meter body (process fluid); -40 to +120°C At transmitter (ambient); -30 to +80°C	
	Relative humidity	10-90% RH	
	Case, Door	Enclosure ; Rain-tight and dust-tight, meets JIS F 8001 class 3 splash-proof, NEMA 3, IEC IP 54 Materials ; Case Aluminum die-cast Door Polyester with fiberglass Door-glass Reinforced glass (3mm thick) Case finish ; Acryl baking finish (for corrosion-resistant and silver finish, refer to the optional specification.) Color of finish; Dark beige (munsell 10YR 4.7/0.5)	
Mounting	Panel or 2-inch pipe mounting		
Weight	Approx. 9.3kg (model KFKB12-1412A1T-X)		

Optional Specifications

Item	Specifications
(1) External SP setting knob (for local setting)	A setting knob is mounted on the door. SP can be adjusted from outside.
(2) Built-in manual controller (with auto/manual transfer switch)	Consists of a manual control regulator, two position transfer switch and balance check button.
(3) Elevation, Suppression	Elevation; The lower limit of input range is above zero. Suppression; The lower limit of input range is below zero.
(4) Air set (not applicable to panel mounting type)	Pressure regulator with filter plus $\phi 40$ mm pressure gauge. (supply pressure: 200 to 990 kPa {2 to 9.9 kgf/cm ² }, output; 140 kPa {1.4 kgf/cm ² }, pressure gauge; 0 to 200 kPa {0 to 2 kgf/cm ² })

Optional Semi-standard and Special Specifications

Item	Applicable Models	Specifications
(1) Steam block (Y29)	Except remote seal diaphragm type	Max. operating pressure; 5 MPa {50 kgf/cm ² } Max. operating temperature ; 250°C (below 120°C at meter body) Steam piping connection ; PT $\frac{1}{4}$ or $\frac{1}{4}$ NPT internal thread Material ; Carbon steel (SF45A)
(2) High temperature use (Y62)	Remote seal diaphragm type	Operating temperature ; Fluid -10 to +200°C Ambient -10 to +80°C Sealing liquid ; Special silicon oil
(3) Stainless steel bolts (Y66)	Model ; KFKB□□-11~16	SUS304 stainless steel is used for meter body fixing bolts.
(4) For oil-free (Y67)	Except remote seal diaphragm type	Liquid-contacting sections are degreased.
(5) Corrosion-resistant and silver finish (Y138)	All the KFK models	Corrosion-resistant finish with baked acryl (Y138A): Resistant against corrosive gases. Corrosion-proof finish with baked epoxy resin (Y138B): Resistant against corrosive liquids. Regular silver finish with baked acryl (Y138C): To suppress temperature rise caused by direct sunlight or other cause. Corrosion-resistant silver finish with baked acryl (Y138D): To suppress temperature rise caused as above and to be resistance against corrosive gases. (note: silver finish is not resistant against alkaline gases.)
(6) For oxygen measurement (Y182)	Remote seal diaphragm type (when measuring element material is SUS316 or SUS316L)	Liquid fill ; Fluorine oil Operating temperature (both fluid and ambient) ; -10 to +60°C Wet-parts treatment ; Treated for degreasing
(7) For chlorine gas measurement (Y183)	Model ; KFKB□□-74~76 (when measuring element material is tantalum.)	Liquid fill ; Fluorine oil Operating temperature (both fluid and ambient) ; -10 to +80°C Wet-parts treatment ; Treated for degreasing.
(8) Special order items (the items mentioned in the right are available as special order items.)	All the KFK models	1) Door lock 2) Stainless steel tag plate 3) AUTO/MAN switch viewing window 4) Pressure gauge ($\phi 40$ mm) for transmitting signal.

Model Number Table

Basic model no.				Selectable specifications								Options
Type	Function	Control action	Type of detector	Cover, flange or mounting screw materials	Element materials	Flange or mounting screw rating	Capillary tube length	Length of extended parts of flange	Air connection	Pressure unit / Output	Mounting method	
KFK	I	II	III	IV	V	VI	VII	VIII	IX	X	XI	

I	B0	Indicating transmitter	
	B1	Indicating controller	(local type)
	B2	Indicating transmitting controller (local type)	
	B3	Indicating controller	(cascade type)
	B4	Indicating transmitting controller (cascade type)	

II	0	No selection	5	PI + Batch
	1	P + Manual reset	6	On-Off
	2	PI	7	Differential gap
	3	PID	8	P + External reset
	4	PD + Manual reset	9	PD + External reset

III	-11	Bourdon tube type	0-5 to 0-70 MPa (0-50 to 0-700 kgf/cm ²)
	-12	Bourdon tube type	0-1.25 to 0-25 MPa (0-12.5 to 0-250 kgf/cm ²)
	-13	Bourdon tube type	0-0.35 to 0-7 MPa (0-3.5 to 0-70 kgf/cm ²)
	-14	Bourdon tube type	0-0.175 to 0-3.5 MPa (0-1.75 to 0-35 kgf/cm ²)
	-15	Bellows type	0-35 to 0-686 MPa (0-0.35 to 0-7 kgf/cm ²)
	-16	Bellows type	0-10 to 0-196 kPa (0-0.1 to 0-2 kgf/cm ²)
	-17	Bellows type	0-3.4 to 0-66.6 kPa (0-25 to 0-500mmHg)
	-18	Bellows type	0-0.7 to 0-13.3 kPa (0-5 to 0-100mmHg)
	-25	Bellows type (abs. press.)	0-35 to 0-686 kPa abs. (0-0.35 to 0-7 kgf/cm ²)
	-26	Bellows type (abs. press.)	0-10 to 0-196 kPa abs. (0-0.1 to 0-2 kgf/cm ²)
	-27	Bellows type (abs.press.)	0-3.4 to 0-66.6 kPa abs. (0-25 to 0-500mmHg)
	-28	Bellows type (abs.press.)	0-0.7 to 0-13.3 kPa abs. (0-5 to 0-100mmHg) abs.
	-71	Remote seal diaphragm type	0-5 to 0-70 MPa (0-50 to 0-700 kgf/cm ²)
	-72	Remote seal diaphragm type	0-1.25 to 0-25 MPa (0-12.5 to 0-250 kgf/cm ²)
-73	Remote seal diaphragm type	0-0.35 to 0-7 MPa (0-3.5 to 0-70 kgf/cm ²)	
-74	Remote seal diaphragm type	0-0.175 to 0-3.5 MPa (0-1.75 to 0-35 kgf/cm ²)	
-75	Remote seal diaphragm type	0-35 to 0-686 kPa (0-0.35 to 0-7 kgf/cm ²)	
-76	Remote seal diaphragm type	0-10 to 0-196 kPa (0-0.1 to 0-2 kgf/cm ²)	

IV	1	Carbon steel (SF45A) (applicable to type 17/18/2□/7□ detector excluding wafer type and diaphragm type)	
	2	SUS316 (except flange type and button diaphragm type)	
	7	SUS304 (applicable to type 7□ detector except wafer)	
	8	SUS316L (applicable to type 7□ detector except button diaphragm and flange)	

V	2	SUS316 (seal diaphragm; SUS316L)	
	3	Monel (applicable to type 11-28 or 7□ detector except extended flange, wafer and button diaphragm type)	
	4	Tantalum	
	8	SUS316L (applicable to type 7□ detector)	

VI		Blank (applicable to type 1□ or 2□ detector)	
	01	Flush diaphragm type 80mm-JIS 10K (RF) equiv. flange	
	02	Flush diaphragm type 80mm-JIS 30K (RF) equiv. flange	
	03	Flush diaphragm type 3"-ANSI 150 (RF) equiv. flange	
	04	Flush diaphragm type 3"-ANSI 300 (RF) equiv. flange	
	05	Extended diaphragm type 100mm-JIS 10K (RF) equiv. flange	
	06	Extended diaphragm type 100mm-JIS 30K (RF) equiv. flange	
	07	Extended diaphragm type 4"-ANSI 150 (RF) equiv. flange	
	08	Extended diaphragm type 4"-ANSI 300 (RF) equiv. flange	
	09	2"-ANSI 1500 (RF) equiv. wafer	
11	PF 1½ external thread (button diaphragm type)		

(applicable to type 7□ detector)

VII		Blank (applicable to type 1□ or 2□ detector)	
	02	2m (applicable to type 7□ detector)	
	03	3m (applicable to type 7□ detector)	
	05	5m (applicable to type 7□ detector)	

VIII		Blank (applicable to type 1□ or 2□ detector)	
	00	Applicable to flush diaphragm, wafer or button diaphragm type.	
	10	Length; 100mm (applicable to extended diaphragm)	
	15	Length; 150mm (applicable to extended diaphragm)	

IX	A	Rc¼ internal thread (instruction plate: Japanese)	
	B	¼NPT internal thread (instruction plate: English)	

X	1	kgf/cm ² (or mmH ₂ O) / 0.2 to 1.0 kgf/cm ²	
	2	PSI / 3 to 15 PSI	
	3	bar / 0.2 to 1.0 bar	
	4	Pa / 20 to 100 kPa	
	8	Pa / 19.6 to 98.1 kPa (equality to 0.2 to 1.0 kgf/cm ²)	

XI	P	Panel mounting (air-set cannot be installed)	
	T	2-inch pipe mounting	





XII	-X	No option	
	-M	Built-in manual controller (with auto/manual switch) (applicable to type B1, B2, B3 or B4 controller.)	
	-K	With external SP setting knob (applicable to type B1 or B2 controller)	
	-5	Elevation or high elevation	
	-6	Suppression	
	-7	With air-set	

[Note] When specifying semi-standard option (Y□) not listed in model no table, please write as: KFKB12-1122A1T-M,K,6,7 (Y67, Y138) (Please consult with factory in case of a multiple of "Y" spec. are required.)

Overall Dimensions

(Unit: mm)

TYPE-11 DETECTOR



TYPE-12, 13, 14 DETECTORS

AIR CONNECTIONS (REFER TO NOTE 1, 3)

- : Rc 1/4 FEMALE
- : 1/4 NPT FEMALE

REGEND

- ESP : EXTERNAL SP SIGNAL
(FOR CASCADE TYPE ONLY)
- X : TRANSMITTING SIGNAL
(FOR TRANSMITTER ONLY)
- OUT : CONTROLLED SIGNAL
- RES : EXTERNAL RESET SIGNAL
(FOR EXTERNAL RESET TYPE ONLY)
- SUP : SUPPLY AIR PRESSURE

Notes:

- 1) The holes not to be used for connection are plugged.
- 2) These holes in the bracket enable the controller to be mounted in various position.
- 3) For manual reset provision, "SUP" and "RES" have been preconnected.
- 4) This dimensions are of bourdon type detector. (detector model nos 11~14). Caution must be taken to dimensions which depend on the shape of elements. (refer to the reference specification sheets at the rear of this sheet.)

Document Number : OM2-5240-1100
Document Name : Pressure Detectors(Meter Bodies)
for PREX3000 Series and KF-B Series
User's Manual

Date : Jan. 2013 (5th edition)
Issued / Edited by : Azbil Corporation

Azbil Corporation